




Parts List : 400230

2013.05

No.	Parts No.	Description	Q'ty
1	042301	Motor Housing	1
2	042302	Rear Cap	1
3	042303	Rear Cap Gasket	1
4	042304	Screw	4
5	042305	Spring Washer	4
6	042306	Anvil Bushing	1
7	042307	Muffle Cover	1
8	042308	Screw	2
10	042310	Protecting Rubber	1
11	042311	Protecting Rubber	1
12	042312	Oil Plug	1
13	042313	Trigger	1
14	042314	Trigger Pin	1
15	042315	Throttle Valve Bushing	1
16	042316	Throttle Valve Stem	1
17	042317	Steel Ball	1
18	042318	Throttle Valve Spring	1
19	042319-1	Hose Fitting (NPT-19T)	1
20	042320	Dust Cover	1
21	042321	Valve Sleeve	1
22	042322	Reverse Valve	1
23	042323	Air Regulator	1

No.	Parts No.	Description	Q'ty
24	042324	O-Ring	1
25	042325	Spring	1
26	042326	Screw	1
27	042327	Pin	1
28	042328	Spring	1
29	042329	Screw	1
30	042330	Rotor Bearing	2
32	042332	Front End Plate	1
33	042333	Spring Pin	1
34	042334	Cylinder	1
35	042335	Rotor	1
36	042336	Rotor Blade	6
37	042337	Rear End Plate	1
38	042338	Spring Pin	1
39	042339	Hammer Cage	1
40	042340	Hammer Pin	1
41	042341	Hammer Dog	1
42	042342	Drive Cam	1
43	042343	Standard Anvil	1
44	042344	O-Ring	1
45	042345	Socket Retainer	1